



Enormous quantities of lumber have been wasted through neglect and carelessness, but much is being done to eliminate waste and conserve the supply of lumber. (See p. 224.)

*A good stand of western yellow pine, Coconino National Forest, Arizona.
(Photo by A. Gaskill. Courtesy U. S. Forest Service.)*

Principles of Woodworking

Herman Hjorth, M.S.

Instructor, Saunders Trades School, Yonkers, N. Y.

Author "Reproduction of Antique Furniture"



The Bruce Publishing Company
New York - Milwaukee, Wis. - Chicago

Copyright, 1930
The Bruce Publishing Company
Printed in the United States of America
(Sixth Printing—1935)

PREFACE

During all ages wood has played an important and friendly part in the development of mankind. It enters, directly or indirectly, into the construction of more manufactured articles than any other material, and there is not an engineering project nor construction of any kind, in which wood is not used in some way.

A material, which enters so extensively into every phase of life, is of tremendous economic value to all civilized nations. The woodworking industries in this country, particularly the building and furniture industries, are among the most important, because they employ thousands of highly skilled workmen, designers, and artists, to produce useful as well as beautiful articles of wood. Other thousands are engaged in the distribution and selling of these products, and still other thousands in the manufacture of the numerous tools and machines used in woodworking.

This text is intended not only for the use of students in secondary and vocational schools, but also for adults who have taken up the study and practice of woodworking as a hobby.

Fundamental tool processes, common to all woodworking trades, have been compiled and arranged in family groups. With these as a basis, cabinetmaking has been emphasized throughout the book, because of its universal interest and appeal, and because this phase of woodworking is probably elected by most students.

All tool operations have been described and written in the form of instruction sheets. These have been further supplemented with related information about materials, tools, and machinery, and by a series of furniture projects, the construction of which has been carefully analyzed and described.

The teacher of woodworking will find the subject matter—both instruction sheets and related information—in convenient form for assignments.

Special attention is called to the method of planning and analyzing the various tool operations involved in the construction of an object. By following this method, any cabinet job may be analyzed and reference made by number to topics describing the various tool operations. After the students have become acquainted with the book, they should do their own thinking and planning, and should formulate their own job sheets for approval by the teacher.

The review questions at the end of each chapter should be of value to the student in testing his knowledge of a given topic, and to the teacher in checking up on his class.

The teacher of general science will find much helpful material on

forest conservation, seasoning of lumber, and the physiological processes of the tree.

The teacher of physics will find the chapter on machinery helpful in illustrating the principles and practical applications of simple machines and the transmission of power.

It is the sincere hope of the author that the increasing number of "home woodworkers" will find this book helpful and stimulating, and that it will contribute to their interest and pleasure in craftsmanship. May they experience that satisfaction and joy of achievement which comes with a piece of work well done.

Grateful acknowledgment is hereby given to the following: Miss S. E. Sievers of Saunders Trades School for valuable help in reading and preparing the manuscript; Mr. J. Macdonald and Mr. H. A. Carlberg of Saunders Trades School for suggestions and criticisms; Mr. Arthur Wakeling, Home Workshop Editor of Popular Science Monthly, for permission to use the material on Wood Turning and Inlaying which was published in a series of articles in that magazine, together with some of the illustrations in topics 255, 325, 326, 327, 328, 330, 334, and 341, which were used in these articles; the Forest Products Laboratory, Madison, Wis., and the National Lumber Manufacturers' Association for most of the illustrations appearing in the chapter on Wood; the Oliver Machinery Company for the illustrations in Figures 97 and 118; and the Editor of the Industrial-Arts Magazine for permission to use material published in that periodical.

Yonkers, N. Y.
January, 1930

HERMAN HJORTH

TABLE OF CONTENTS

<i>Chapter</i>	<i>Page</i>
PREFACE	v
I. HAND TOOLS	1
1. Bench. Measuring Tools. 2. Rule. 3. Measuring Tapes. 4. Try-Squares. 5. Miter and Try-Squares. 6. Sliding T Bevels. 7. Steel Square. 8. Brace Measure. 9. Octagon Measure. 10. Board Measure. 11. Rafter Table. 12. Marking Gauge. 13. Panel Gauge. 14. Slitting Gauge. 15. Mortising Gauge. 16. Butt Gauge. 17. Dividers or Compasses. 18. Trammel Points. 19. Inside and Outside Calipers. 20. Plumb and Level. 21. Plumb Bob. Saws. 23. Ripsaw. 24. Crosscut Saw. 25. Backsaw. 26. Dovetail Saw. 27. Compass Saw. 28. Keyhole Saw. 29. Turning Saw. 30. Hack Saw. 31. Coping Saw. 32. Miter Box. Planes. 34. Jack Plane. 35. Fore Plane. 36. Jointer. 37. Smooth Plane. 38. Circular Plane. 39. Block Plane. 40. Bullnose Plane. 41. Rabbit-and-Fillister Plane. 42. Dado Plane. 43. Match Plane. 44. Router Plane. 45. Universal Plane. 46. Molding Planes. 47. Plane Gauges. 48. Spokeshave. 49. Scrapers. Chisels. 51. Firmer Chisel. 52. Paring Chisel. 53. Framing Chisel. 54. Butt Chisel. 55. Mortise Chisel. 56. Gouges. 57. Carving Tools. 58. Drawknife. Boring Tools. 59. Auger Bits. 60. Dowel Bits. 61. Car Bits and Ship Augers. 62. Expansion Bits. 63. Gimlet Bits. 64. Twist Bits. 65. Forstner Bits. 66. Bradawl. 67. Countersink. 68. Plug and Washer Cutters. 69. Plain Brace. 70. Ratchet Brace. 71. Bit-Brace Extension. 72. Auger-Bit Gauges. 73. Automatic, Reciprocating, and Hand Drills. Miscellaneous Tools. 75. Plain Screw Drivers. 76. Automatic Screw Drivers. 77. Screw-Driver Bits. 78. Claw Hammer. 79. Nail Sets. 80. Mallets. 81. Hatchets. 82. Rasps and Files. 83. Steel Bar Clamps. 84. C Clamps. 85. Column Clamps. 86. Hand Screws. 87. Monkey Wrench. Review Questions.	
II. MACHINE TOOLS	27
89. Swing Cut-Off Saws. 90. Use of Swing Cut-Off Saw. 91. Under-Swing Cut-Off Saw. 92. Circular Saw. 93. Directions for Using Circular Saw. 94. Band Saw. 95. Jig Saw. 96. Jointer or Hand Planer. 97. Directions for Adjusting Tables. 98. Planer or Surfacer. 99. Mortising Machines. 100. Shaper. 101. Portable Shapers and Routers. 102. Wood Trimmer. 103. Belt Sander. 104. Disk Sanders. 105. Spindle Sander. 106. Drum Sanders. 107. Portable Sanders. 108. Sharpening Machines. 109. Automatic Knife Grinders. Review Questions.	
III. THE SHARPENING OF TOOLS	54
Sharpening Ripsaws and Crosscut Saws. 111. Jointing Saws. 112. Setting Saws. 113. Filing Ripsaws. 114. Filing Crosscut Saws. 115. Sharpening a Plane Iron. 116. Sharpening Gouges. 117. Sharpening and Adjusting a Veneer Scraper. 118. Sharpening a Cabinet Scraper. 119. Sharpening an Auger Bit. Sharpening Turning Tools. 120. Gouge.	

<i>Chapter</i>	<i>Page</i>
121. Square-Nose Chisel. 122. Skew Chisel. 123. Parting or Cut-Off Tool. 124. Round-Nose Chisel. 125. Diamond-Point or Spear-Point Chisel. 126. Right or Left Skew Chisel. 127. Cleaning a Rasp or File. Sharpening Circular Saws. 128. Jointing Circular Saws. 129. Filing Circular Saws. 130. Gumming Circular Saws. 131. Setting Circular Saws. 132. Side Filing Circular Saws. 133. Brazing Band Saws. Sharpening Band Saws. 134. Setting Band Saws. 135. Filing Band Saws. 136. Sharpening Planer or Trimmer Knives. Review Questions.	
IV. PLANING AND SQUARING TO DIMENSIONS	70
138. Squaring Boards to Dimensions. 139. Jointing Boards for Gluing. 140. Squaring a Table Top. 141. Making and Squaring Table Top with Machine Tools. 142. Squaring Table and Cabinet Legs. 143. Tapering Square Legs for Tables and Cabinets. 144. Tapering Square Legs on the Circular Saw. Review Questions.	
V. GROOVED JOINTS	79
146. Making a Rabbet Joint. 147. Making a Dado Joint. 148. Making a Gain Joint. 149. Making a Grooved Joint. 150. Making a Groove and Rabbet Joint. 151. Making a Dado and Rabbet Joint. To Make Grooved Joints with Machine Tools. 152. Cutting Grooves, Dadoes, and Rabbets with a Dado Head. 153. Cutting Grooves, Dadoes, and Rabbets with a Circular Saw. 154. Cutting Tongues, Grooves, and Rabbets on a Shaper. Review Questions.	
VI. DOWEL JOINTS	85
156. Making a Doweled Joint. 157. Joining Legs to a Turned Column with Dowels. Review Questions.	
VII. LAP OR HALVING JOINTS	90
159. Making an End-Lap Joint. 160. Making an End-Lap Joint with Rabbet. 161. Making a Cross-Lap Joint. 162. Making a Dovetail-Lap Joint. Review Questions.	
VIII. MORTISE-AND-TENON JOINTS	94
164. Making a Blind Mortise-and-Tenon Joint. 165. Making a Haunched Mortise-and-Tenon Joint. 166. Making a Through Mortise-and-Tenon Joint. 167. Making a Slip Joint. 168. Making a Mortise on a Mortising Machine. 169. Cutting Tenons on the Circular Saw. Review Questions.	
IX. DOVETAIL JOINTS	103
171. Making a Through, Multiple, Dovetail Joint. 172. Making a Half-Lap, Multiple, Dovetail Joint. Review Questions.	
X. MISCELLANEOUS CONSTRUCTIONS	107
174. Making a Drawer. 175. Making Drawer Rails and Guides. 176. Making a Panel Structure. 177. Making a Miter Joint. 178. Nailed Miter. 179. Doweled Miter. 180. Slip-Feather Miter. 181. Spline Miter. 182. Making a Rule Joint. 183. Making a Finger	

<i>Chapter</i>	<i>Page</i>
Joint. 184. Making Slide Supports. 185. Making a Checkerboard. Review Questions.	
XI. GLUING AND CLAMPING	119
187. Preparing Glue. 188. Gluing Directions. 189. Gluing Boards Edge to Edge. 190. Gluing Frame or Panel. 191. Gluing Bookshelves. 192. Gluing a Cabinet. 193. Gluing a Drawer. 194. Gluing a Chair. 195. Gluing Miters or Irregular Shapes. 196. Gluing Doweled Joints and Segments. Review Questions.	
XII. APPLICATION OF HARDWARE	130
198. Applying Screws. 199. Fastening Table Top. 200. Fastening Hinges. 201. Attaching Locks. Fastening Catches and Bolts. 202. Elbow Catches. 203. Door Bolts. 204. Flush Bolt. 205. Ball Catches. 206. Table Catch. Attaching Casters, Glides, and Chair Tips. 207. Casters. 208. Glides. 209. Chair Tips. 210. Furniture Pulls and Knobs. Review Questions.	
XIII. WOOD TURNING	140
212. History. 213. Lathe and Parts. 214. Bed. 215. Headstock. 216. Countershaft. 217. Tailstock. 218. Toolrest. 219. Chucks and Faceplates. 220. Lathe Speed. 221. Centering and Clamping Stock in Lathe. 222. Turning Plain Cylinder. 223. Making Shoulder Cuts. 224. Making Taper Cuts. 225. Making Concave Cuts. 226. Making Convex Cuts. 227. Sanding in Lathe on a Spindle. 228. Turning a Disk. 229. Sanding in Lathe on a Disk. 230. Chuck Turning. 231. Split Turning. Review Questions.	
XIV. SURFACE DECORATION	166
233. General Suggestions. Inlaying. 234. Inlaying Lines or Bands. 235. Inlaying Insets. 236. Cutting Straight Reeds. 237. Cutting Spiral Reeds. 238. Carving a Single Spiral on a Turned Cylinder. 239. Carving a Double Spiral on a Turned Cylinder. 240. Laying Out Tapered Spirals. Simple Carving. Tools. 241. Carving Beads. 242. Carving Chamfers and Hollows. 243. Carving Borders. Moldings. 244. Making Moldings. 245. Mitering and Applying Moldings. 246. Coping Moldings. 247. Shaping Table-Top Edges. 248. Matching and Applying Veneers. 249. Gluing Veneers. 250. Overlays, Frets, or Veining. 251. Decalcomania Transfers. Review Questions.	
XV. UPHOLSTERY	196
253. History. 254. Plain Pad Seat. 255. Pad Seat with a Roll Edge. 256. Upholstering a Slip Seat. 257. Weaving a Fiber Seat. 258. Weaving a Cane Seat. 259. Applying Cane Webbing. Review Questions.	
XVI. WOOD FINISHING	212
261. Preparing the Surface. Stains. 262. Water Stains. 263. Spirit Stains. 264. Oil Stains. 265. Acid Stains. 266. Staining Directions. 267. Wood Filler. Finishing Coats. 268. Shellac. 269. Lacquer. 270. Varnish. 271. Wax. 272. Linseed Oil. 273. Summary of Advantages	

27. What is the difference between a cabinet scraper and a hand scraper?
28. Why should all planing and scraping be completed before sanding?

Chisels

29. What is the difference between a socket and a tang chisel?
30. Why is there a metal ring around the handle of a tang chisel?
31. Name the most common chisels, and indicate the chief use of each.
32. How does a gouge differ from a chisel as to shape and use?

Boring Tools

33. What is the difference between a bit and a drill?
34. What is the function of each of the following parts of an auger bit: spur, nibs, lips?
35. How is the size indicated on auger bits, Forstner bits, twist bits, and gimlet bits?
36. What type of screw point should be used for boring in end wood with an auger bit?
37. What kind of boring tools should be used for the following operations:
 - a) To bore for a $\frac{1}{2}$ -in. dowel.
 - b) To bore for a $1\frac{1}{2}$ -in. flathead screw.
 - c) To bore a hole $1\frac{3}{4}$ in. in diameter.
 - d) To bore in end wood.
 - e) To bore a hole $\frac{1}{2}$ in. in diameter and 16 in. long.
 - f) To bore a hole $\frac{3}{4}$ in. in diameter and 16 in. long.
 - g) To bore for a $\frac{1}{2}$ by 4-in. roundhead screw.
 - h) To bore a $\frac{7}{16}$ -in. hole in $\frac{1}{4}$ -in. stock.
 - i) To cut a circular leather disk 2 in. in diameter.
38. What is understood by the word "sweep" as applied to braces?
39. What is an auger-bit gauge, and how is it used?
40. What is a hand drill?

Miscellaneous Tools

41. Why is it easier to drive a large screw with a screw driver 18 in. long than with one 8 in. long?
42. What is the chief advantage of (a) an automatic screw driver, and (b) a screw-driver bit?
43. What advantage has a "bell-faced" hammer over a common hammer?
44. Compare the blows of a hammer with those of a mallet.
45. What is the shape and use of a hatchet?
46. What is the difference in shape and use between a rasp and a file for wood?
47. Differentiate between carriage-maker's clamps, bar clamps, and column clamps.
48. What are the parts of a hand screw?
49. How is a hand screw applied and tightened on a piece of work?
50. Name five jobs for which a woodworker may have to use one or more of the following tools: monkey wrench, tinner's snips, cutting pliers, gas pliers.

CHAPTER II MACHINE TOOLS

During recent years there has been considerable progress in the field of woodworking machinery. Particular attention has been given to greater safety for the operator, and to convenience and ease in both the "setting up" and the operation of the machinery. Old types of production machines have been improved, and new types have been invented. Moreover, numerous types of bench and portable machines have been developed.

Since woodworking machinery is very dangerous to operate, improvements and inventions that will safeguard the operator are of the greatest importance. Some of the most notable advances have been cylindrical cutting heads on hand planers, safety switches, improved guarding devices, and the elimination of fast-moving belts through direct motor drives.

Developments within the field of production machinery have completely revolutionized the furniture industry, and have made cabinet-making in its century-old form one of the disappearing trades. In large furniture factories, handwork has been reduced to a minimum, because machines have been invented which can be operated by semi-skilled workers. Such machines perform practically all tool operations faster, better, and more uniformly than the skilled workman can by hand methods.

While a discussion of production machinery is interesting, both from a mechanical and a commercial point of view, it has no place in this book, which deals mainly with handwork, hand tools, and the simpler and more commonly used woodworking machines and operations.

The development of the small bench and portable machines, on the other hand, is of interest to the manufacturer and the individual workman, as well as to students of woodworking, and the increasing number of amateurs, who find recreation, satisfaction, and joy in manual work. Large up-to-date factories have found it to their advantage to distribute a number of these small machines among their benchworkers, because they help to speed up production by eliminating practically all handsawing and planing.

For the same reasons, contractors and individual workmen use them in increasing numbers, not only for sawing and planing, but also for routing, shaping, boring, and sanding.

This type of machinery has also become very popular in schools, es-

TABLE OF CONTENTS

<i>Chapter</i>	<i>Page</i>
and Disadvantages of the Finishing Coats. To Paint Furniture and Interior Woodwork. 274. Preparing the Surface. 275. Applying Priming Coat. 276. Filling Holes and Imperfections. 277. Applying Undercoats. 278. Finishing Coats. Review Questions.	
XVII. WOOD	223
280. Botanical Division of Trees. 281. Life Function of Trees. 282. Man's Dependence on Plants. 283. Conservation of Lumber. Structure of Wood. 284. Cell Formation. 285. Annual Rings. 286. Heartwood and Sapwood. 287. Cambium. 288. Bark. 289. Medullary Rays. 290. Porous Woods. 291. Weight of Wood. 292. Reproduction of Trees. 293. Logging Operations. 294. Sawing Logs. 295. Plain- and Quarter-Sawing. 296. Seasoning Wood. 297. Air Seasoning. 298. Kiln Seasoning. 299. Moisture Content. 300. Types of Kilns. 301. Wood Shrinkage. 302. Drying Defects. Manufactured Lumber. 303. Standard Lengths and Thicknesses of Lumber. 304. Allowance for Planing. 305. Board Measure. Types of Manufactured Lumber. 306. Matched, Grooved, and Beaded Boards. 307. Moldings. 308. Veneers. 309. Plywood. 310. Uses of Plywood. 311. Manufactured Boards. Selection and Uses of Lumber. 312. Lumber for Cabinetwork and Interior Woodwork. 313. Lumber for Building. 314. Principal Cabinet Woods. 315. Principal Woods Used in Building. Review Questions.	
XVIII. APPLIED PROJECTS	250
317. Preliminary Steps in Construction. 318. Making Drawings and Blue Prints. 319. Reading Working Drawings. 320. Reading Drawing of Bookrack. 321. Bookrack. Suggested Order of Tool Operations. 322. Reading Drawing of Footstool. 323. Footstool. Tool Operations. 324. Reading Drawing of Early English Gate-Leg Table. 325. Early English Gate-Leg Table. Tool Operations. 326. Serving Tray. Tool Operations. 327. Mirror Frame. Tool Operations. 328. Stand. Tool Operations. 329. Lamp Standard. Tool Operations. 330. End Table. Tool Operations. 331. Stool. Tool Operations. 332. Occasional Table. Tool Operations. 333. Umbrella Stand. Tool Operations. 334. Cabinet. Tool Operations. 335. Bedside Table. Tool Operations. 336. Base and Column. 337. Bedside Table Top. 338. Chess Table Top. 339. Sewing-Table Top. 340. Dining Chair. Tool Operations. 341. Chest. Tool Operations.	
INDEX	303

Principles of Woodworking

CHAPTER I HAND TOOLS

The woodworker uses a large variety of hand tools. Every workman should be familiar with the tools which he uses. He should know their proper names, the purpose for which each is used, and how they are sharpened and kept in good condition.

In this chapter a brief description is given of the most commonly used hand tools. In a later chapter the sharpening of tools is explained in detail.

1. **The bench** is a tool or appliance of the utmost importance to the woodworker. The best type of bench has a top that is constructed of narrow strips of hard wood, glued and bolted together. It usually has




Fig. 1. Workbench

a recess or trough in which tools may be placed while working. The top is bolted to a frame consisting of four legs braced securely with cross-pieces. This frame is often fitted with one or more drawers. (Fig. 1.)

The bench top is equipped with a side vise and sometimes also with a tail vise. These vises are made either of wood or iron. They have a central screw and parallel guide bars, one on each side of the screw. (Fig. 2.) Some iron vises are of the "continuous-screw" type and others of the "quick-acting" type. On some quick-acting vises a section of the screw thread is cut away throughout the entire length of the screw. This permits the movable vise jaw to be pulled in or out when the screw is in a certain position. A partial turn to the right tightens these quick-acting vises.




Fig. 2. Quick-acting vise

Some vises are equipped with an adjustable dog; i.e., a piece of iron which moves in a slot in the vise jaw. It can be set flush with the top of the vise jaw, or raised above it. A corresponding bench stop fits into holes bored in the bench top so that a piece of wood may be clamped firmly between the bench stop and the vise jaw.

A tail vise is a great convenience on a workbench, because it permits of clamping long pieces, such as table legs, for planing or mortising.

MEASURING TOOLS

2. A rule is generally the first tool used by the woodworker. Rules are made in different lengths and of different materials. Those used by the woodworker are usually of the folding type, and measure from 2 to 8 ft. in length. (Fig. 3.) Rules are generally marked off on both sides in inches and subdivisions of an inch, but they are also made with inch divisions on one side and metric divisions on the other.




Fig. 3. Folding rule

3. Measuring tapes are used by carpenters, contractors, and architects. They are made of steel or cloth, and usually measure from 25 to 100 ft. in length. (Fig. 4.) They are divided into inches and feet, or meters and centimeters.




Fig. 4. Steel tape

4. Try-squares are used for testing the squareness of lumber, and in checking the squareness of work being assembled, especially in places where the framing square would be too large. Try-squares consist of two parts, the stock and the blade, which are firmly fastened together at right angles. The stock

is thick and is made of wood or iron. The blade, which is thin, is made of steel and has an inch scale stamped on it. (Fig. 5.) Try-squares are made in sizes of from 4 to 12 in., measured from the end of the blade to the stock.

5. Miter and try-squares (Fig. 6.) can be used at both 90 and 45 deg. Miter squares can only be used for angles of 45 deg.




Fig. 5. Try-square




Fig. 6. Miter and try-square




Fig. 7. Sliding T bevel

6. Sliding T bevels (Fig. 7) are similar to try-squares, but differ in that their blades are adjustable to any angle. They are used for laying out angles other than right angles, as for instance corner braces, dovetails, or side rails for chairs.

7. The steel square measures 16 by 24 in., or 18 by 24 in., and is of the same thickness, about $\frac{1}{8}$ in., throughout. The 24-in. part is called the "blade" or "body," and is 2 in. wide. The 16- or 18-in. part is called the "tongue," and is $1\frac{1}{2}$ in. wide. The "face" of the square is the side on which the manufacturer's name is stamped. The steel square is a very important tool, especially to the carpenter, who uses it in laying out the many different cuts employed in roof framing, stair building, oblique joints, etc. The cabinetmaker uses it mostly for testing the flatness of large surfaces (Art. 189) and for testing for squareness in gluing. The uses of the steel square are so numerous and varied that whole books have been written on this subject.

Besides the divisions of the inch into eighths, tenths, twelfths, sixteenths, and thirty-seconds, which are marked on the inside and outside




Fig. 8. Brace measure

edges on both sides of the square, the following tables are marked on it: brace measure, octagon measure, board measure, rafter table, and the divisions of 1 in. into 100 parts.

Planes, like saws, are made in many different forms for different planing jobs. Some of the most common types are as follows:

34. The jack plane is the most useful, all-around plane in the woodworker's kit. (Fig. 36.) It is 14 or 15 in. long, and consists of an iron body to which the plane iron can be clamped. The bottom of the plane, which is either smooth or corrugated, is called the "sole." The front part of the sole is called the "toe," and its rear part, the "heel." A casting, called the "frog," is screwed to the iron body near its center. A wooden knob is screwed to the forward part of the body, and a handle to its rear part.




Fig. 36. Jack plane

The plane iron, which in a jack plane is 2 in. or $2\frac{1}{4}$ in. wide, consists of two parts, the cutter and the cap. The latter is screwed to the back of the cutter, and is used to stiffen it and to break up the shavings. The plane iron is clamped to the frog by means of another iron, corresponding to the wedge in a wooden plane, called the "lever cap." The plane iron can be adjusted to the depth of the cut by means of a brass screw engaging a wishbonelike casting. This is called the "Y adjustment." It can be adjusted laterally or level with the sole of the plane, by a lever riveted to the top of the frog. (Fig. 37.)




Fig. 37. Plane parts. 1, cutter iron; 2, plane-iron cap; 3, cap screw; 4, lever cap; 5, frog; 6, Y adjustment; 7, Y-adjustment screw; 8, lateral-adjustment lever; 9, handle; 10, knob

The sole of the plane keeps the thickness of the shaving uniform. If the board to be planed is uneven, it prevents the cutting iron from touching the hollow parts until all the high parts have been leveled off. Therefore, the longer the sole, the straighter the edge that is produced. The shavings enter through a narrow slit called the "throat" or "mouth." This slit is in the sole just forward of the cutting iron. The toe of the plane presses down on the wood in front of the shaving being taken, thus preventing it from splitting ahead. The width of the throat can be narrowed by moving the frog forward.

When planing an edge or a narrow board, the entire sole of the plane should be in contact with the wood to produce a straight edge. The tendency among beginners to hold the plane obliquely should be avoid-

ed and discouraged. Oblique cutting is a little easier, but it does not produce a flat surface, because only a small part of the sole is in contact with the wood.

35. The fore plane is built exactly like a jack plane, but is 18 in. long and has a plane iron $2\frac{3}{8}$ in. wide.



Fig. 38. Jointer



Fig. 39. Smooth plane

36. The jointer is also like the jack plane, but is 22 to 24 in. long, and has a plane iron $2\frac{3}{8}$ or $2\frac{5}{8}$ in. wide. (Fig. 38.) The latter two planes are used for leveling larger surfaces and for jointing the edges of boards to be glued.

37. The smooth plane is of the same construction as the above-named planes, but it is shorter, being from $5\frac{1}{2}$ to 10 in. in length. (Fig.




Fig. 40. Circular plane




Fig. 41. Block plane

39.) It also has narrower plane irons, from $1\frac{1}{4}$ to 2 in. It is used for planing smaller pieces and for very fine work.

38. The circular plane differs from the others in that it has a flexible bottom 10 in. long, which can be adjusted to either convex or concave curves. (Fig. 40.) It is used on curved work, such as round table tops and aprons.

39. The block plane is a small plane from 4 to 8 in. long. (Fig. 41.) It has only a single plane iron, which is placed at a very low angle with the beveled side up. The lever cap is generally curved so that it fits smoothly within the hollow of the hand. This plane is used for planing end wood and in places where an ordinary plane could not be used.

40. The bullnose rabbet plane is about 4 in. long, and has the plane iron fastened to the extreme front of the body. (Fig. 42.)



Fig. 42. Bullnose rabbet plane

27. What is the difference between a cabinet scraper and a hand scraper?
28. Why should all planing and scraping be completed before sanding?

Chisels

29. What is the difference between a socket and a tang chisel?
30. Why is there a metal ring around the handle of a tang chisel?
31. Name the most common chisels, and indicate the chief use of each.
32. How does a gouge differ from a chisel as to shape and use?

Boring Tools

33. What is the difference between a bit and a drill?
34. What is the function of each of the following parts of an auger bit: spur, nibs, lips?
35. How is the size indicated on auger bits, Forstner bits, twist bits, and gimlet bits?
36. What type of screw point should be used for boring in end wood with an auger bit?
37. What kind of boring tools should be used for the following operations:
 - a) To bore for a $\frac{1}{2}$ -in. dowel.
 - b) To bore for a $1\frac{1}{2}$ -in. flathead screw.
 - c) To bore a hole $1\frac{3}{4}$ in. in diameter.
 - d) To bore in end wood.
 - e) To bore a hole $\frac{1}{2}$ in. in diameter and 16 in. long.
 - f) To bore a hole $\frac{3}{4}$ in. in diameter and 16 in. long.
 - g) To bore for a $\frac{1}{2}$ by 4-in. roundhead screw.
 - h) To bore a $\frac{7}{16}$ -in. hole in $\frac{1}{4}$ -in. stock.
 - i) To cut a circular leather disk 2 in. in diameter.
38. What is understood by the word "sweep" as applied to braces?
39. What is an auger-bit gauge, and how is it used?
40. What is a hand drill?

Miscellaneous Tools

41. Why is it easier to drive a large screw with a screw driver 18 in. long than with one 8 in. long?
42. What is the chief advantage of (a) an automatic screw driver, and (b) a screw-driver bit?
43. What advantage has a "bell-faced" hammer over a common hammer?
44. Compare the blows of a hammer with those of a mallet.
45. What is the shape and use of a hatchet?
46. What is the difference in shape and use between a rasp and a file for wood?
47. Differentiate between carriage-maker's clamps, bar clamps, and column clamps.
48. What are the parts of a hand screw?
49. How is a hand screw applied and tightened on a piece of work?
50. Name five jobs for which a woodworker may have to use one or more of the following tools: monkey wrench, tinner's snips, cutting pliers, gas pliers.

CHAPTER II MACHINE TOOLS

During recent years there has been considerable progress in the field of woodworking machinery. Particular attention has been given to greater safety for the operator, and to convenience and ease in both the "setting up" and the operation of the machinery. Old types of production machines have been improved, and new types have been invented. Moreover, numerous types of bench and portable machines have been developed.

Since woodworking machinery is very dangerous to operate, improvements and inventions that will safeguard the operator are of the greatest importance. Some of the most notable advances have been cylindrical cutting heads on hand planers, safety switches, improved guarding devices, and the elimination of fast-moving belts through direct motor drives.

Developments within the field of production machinery have completely revolutionized the furniture industry, and have made cabinet-making in its century-old form one of the disappearing trades. In large furniture factories, handwork has been reduced to a minimum, because machines have been invented which can be operated by semi-skilled workers. Such machines perform practically all tool operations faster, better, and more uniformly than the skilled workman can by hand methods.

While a discussion of production machinery is interesting, both from a mechanical and a commercial point of view, it has no place in this book, which deals mainly with handwork, hand tools, and the simpler and more commonly used woodworking machines and operations.

The development of the small bench and portable machines, on the other hand, is of interest to the manufacturer and the individual workman, as well as to students of woodworking, and the increasing number of amateurs, who find recreation, satisfaction, and joy in manual work. Large up-to-date factories have found it to their advantage to distribute a number of these small machines among their benchworkers, because they help to speed up production by eliminating practically all handsawing and planing.

For the same reasons, contractors and individual workmen use them in increasing numbers, not only for sawing and planing, but also for routing, shaping, boring, and sanding.

This type of machinery has also become very popular in schools, es-